



# CUP HOLDER

## INSTRUCTION MANUAL




### REQUIRED TOOLS:



# GENERAL INSTRUCTIONS

The easiest way to mount the T-Slot Click-in-Nuts, is to slide them in from one side of the profile, with the ball facing down. But don't worry if you need to put in a click-in-nut in a profile which has both ends already closed: it is also possible to push them in the T-slot anywhere you like!



## INCLUDED ITEMS



Cup Holder  
1x




M5x20  
2x



M5 T-Nut  
2x

1



2

