



# SINGLE MONITOR STAND 4040

## INSTRUCTION MANUAL




### REQUIRED TOOLS:




# GENERAL INSTRUCTIONS


The easiest way to mount the T-Slot Click-in-Nuts, is to slide them in from one side of the profile, with the ball facing down. But don't worry if you need to put in a click-in-nut in a profile which has both ends already closed: it is also possible to push them in the T-slot anywhere you like!




## INCLUDED ITEMS




4040 L=500  
2x




4040 L=950  
1x




8040 L=1170  
2x




Rubber Foot  
4x




Perpendicular Plate  
2x




Corner Bracket  
4x




Cover 4040  
6x



Cover 8040  
2x



M8x16  
8x



M8x16 (Black)  
8x




M5x12  
4x



M8 T-Nut  
16x






M5 T-Nut  
4x



**1**

Attach the rubber feet and the corner brackets to the 4040 L=500 profiles. Perform this step twice.





8040 L=1170

2x



M8x16

4x





M8 T-Nut

4x


2

Mount the 8040 profiles.  
Perform this step twice.





Perpendicular Plate  
**2x**






M8x16 (Black)  
**4x**




M8 T-Nut  
**4x**

**3**


Perform this step twice.





4040 L=950

1x



M8x16 (Black)


4x




M8 T-Nut


4x

4






Cover 4040  
6x



Cover 8040  
2x

5


Place all cover caps on the end of the profiles.



6

This monitor stand had the option of 'Standard VESA Bracket' and 'Easy Monitor Alignment Kit'. Both these monitor mounting solutions have their own manual. Please proceed the build of your monitor stand by using one of these. Find them at <https://www.treq-sim.com/manuals>

## EASY MONITOR ALIGNMENT KIT



## STANDARD VESA BRACKET

